

## DEMA TRAPPER Automated Dosing System INSTALLATION INSTRUCTIONS

### NOTES

- Approximate Automated Dosing Pump dimensions: 175mm Width x 180mm Height x 150mm Depth.
- The dosing pump will reach you pre-programmed to meet your requirements.
- Batteries should last approximately 18 months under normal operating conditions.
- Additional instructions for pump mounting and connection can be found with the pump including troubleshooting suggestions.

### MOUNTING



- Select a dry location close to a drain pipe that leads to the waste treatment system (e.g. under the sink is usually the most appropriate).
- Ensure there is enough room to store the relevant EcoCare product container.
- Ensure the pump mounting location is close enough to allow for tubing to reach from product container to pump and from pump to drain pipe.
- Use the screws and mounting provided to mount the unit on the wall similarly to hanging a picture frame.
- Drill a hole into the drain pipe into which the product will be dispensed via the tubing.

### PUMP CONNECTION



- Drill a hole into the lid of the product container.
- Insert the short straight tubing into the hole drilled into the product container. Make sure the tubing reaches the bottom of the product container. Secure the other end of the short straight tubing to the left inlet of the pump.
- Insert the long tubing into the hole drilled into the drain pipe and secure with sealant. Attach the other end of the long tubing to the right outlet of the pump.

### PRIMING



- Press any button (once) to wake up the controls.
- With the display on, press and hold the right arrow key for 2 seconds to start the prime.
- You should hear the pump activate and see liquid flow through the tubing.
- Once the tubes have been completely filled with liquid, press the right arrow again to stop priming.